

REPLACEMENT OF THE TELESCOPIC HANDLE

TOOL(S)

Screwdriver with square bit



1 Locate the position of the telescopic handle on the outside.



2 Open the bag to access the bottom lining of the bag.



3 Unhook the lining at the bottom of the bag to access the screws.



4 Using a screwdriver, unscrew the screws from inside the bag.



5 Repeat the operation on all 6 screws. Remove the telescopic handle.



6 Install the new telescopic handle by starting with screwing in two screws with washers. Ensure proper alignment of the bag's holes with those of the telescopic handle casing before screwing.



7 Repeat the operation on all 6 screws. The screwing should be done until a slight compression of the material becomes visible.



8 Reattach the linings to their Velcro fasteners. Check for proper functioning.

Bag PRO

Business In Motion Inc.
12081 Katy Rd. Suite 809
Fort Worth, TX 76244
UNITED STATES

HERE WE GO AGAIN